## Installation of camera driver

(IEEE1394 cameras following DCAM- Standard and compatible with OCHILynx-1394-Hostconroller driver)

Step 1.

Step 2.


Step 3 (… to get popup menu use right mouse button …).

Step 4.

Texas Instruments OHCI Compliant IEEE 1394 Host Controller ...   **? X**

General | Driver | Resources |

Texas Instruments OHCI Compliant IEEE 1394 Host
Controller

Device type:	IEEE 1394 Bus host controllers
Manufacturer:	Texas Instruments
Location:	Location 2 (PCI bus 0, device 15, function 0)

Device status

This device is working properly.

If you are having problems with this device, click Troubleshooter to
start the troubleshooter.

Troubleshooter...

Device usage:

Use this device (enable)

OK   Cancel

Step 5.

Texas Instruments OHCI Compliant IEEE 1394 Host Controller ... ? ☒

General | Driver | Resources |

Texas Instruments OHCI Compliant IEEE 1394 Host
Controller

Driver Provider: Microsoft

Driver Date: 11/14/1999

Driver Version: 5.0.2183.1

Digital Signer: Microsoft Windows 2000 Publisher

To view details about the driver files loaded for this device, click Driver
Details. To uninstall the driver files for this device, click Uninstall. To update
the driver files for this device, click Update Driver.

[Driver Details...]   [Uninstall]   [Update Driver...]

[OK]   [Cancel]

Step 6.

Step 7.

Step 8.

Step 9.

Step 10.

Step 11.

Step 12.

Step 13.

Step 14.